

## Convertible Crib Directions

Congratulations! You are now a proud owner of the only Convertible Log Crib on the market today! It is beautifully handcrafted and durable, we are confident you will find that it will serve you and your family well for generations. Upon delivery, you will find all the pieces on your pallet to assemble all three phases of the complete Convertible Crib—including the Crib, Toddler bed, and Full-size bed.

### The pieces included are:

--the Front Gate/footboard



--the Large Back Panel/Headboard



--2 smaller Side Panels



--2 long metal & Half log bed rails,  
measuring approx 79”L





--2 individual posts measuring approx 46" H



--1 shorter metal & Half log bed rail,  
measuring approx 50" L



--a plastic bag or small box with  
5/16"x1" nuts and lock washers



--a 1/2" plywood Mattress Deck  
(approx 27"Wx52"L)

**Crib Assembly:** The first phase of your 3 beds in One is the Crib. You will not need the 2 individual posts, any of the 3 metal & half-log side rails, or the hardware (bolts & washers). You WILL need eight 2" woodscrews (not included), a drill, and a 1/8" or smaller drill bit.

1. First stand up the Large Back Panel with the 1.5" holes facing you and position the Front Gate directly in front facing the Back Panel, with the holes facing toward the Back Panel.
2. Simply take each of the smaller side panels and match up their corresponding red numbers on the ends with the numbers inside the holes, and slide them in as far as you can (do NOT glue).



You might use a rubber mallet (gentler on finished cribs) or ratchet strap to make sure they stay in



place.

3. Now lower the plywood mattress deck inside the Crib. Once the deck is in place, you can cinch the ratchet strap down to make sure it is snug on the deck. We cannot glue at this stage if you intend to use the Toddler bed and full-size bed as these pieces will be rotated out, then back in later.

4. Where the Side panel slides into the hole, drill a small pilot hole from the bottom through the “tenon” and into the post, not more than 2” deep.



Then you can countersink a 2” wood screw to hold the side panels in place. Do this on top and bottom (all four holes per side panel).



5. Your new Crib is now complete, simply place the crib mattress inside, and your baby now has a beautiful new Log Crib.



Note: The latch on the gate is simple to use. To lock the gate, simply slide the peg all the way in and turn the knob clockwise to lock it. To unlock the gate, simply twist the knob counter-clockwise and slide it back out. Be sure to open both left and right sides before opening the gate.



**Toddler Bed:** To transition from the Crib to the Toddler Bed is very simple and can be done with one person, but 2 people makes it very quick and easy. You will need to get the two 46" posts and the short metal & half-log side rail out of storage for this step. Essentially, all you are doing is removing the Front Gate, replacing it with 2 individual posts, and adding a short rail in the front. You will need your drill to remove the screws, and a 7/16" socket or wrench.

1. Remove the mattress and mattress deck from inside the Crib.
2. Unscrew the woodscrews (from Step 4 above) on the Side Panels attaching to the Front Gate, top and bottom both sides, but NOT the ones in the back attached to the Back Panel.
3. Slide the Front Gate off the Side Panel and replace with the Separate 46" H Posts with the corresponding numbers inside the holes. Do this for both left and right, removing the Front Gate and storing it until ready to transition to the Full-size bed. Using same holes, replace wood screws into front posts.
4. Once the posts are in place, take the short metal and half log rail and match up the red numbers corresponding with the front posts and side panels. Bolt the metal bracket on the small mattress rail into the corresponding metal inserts located on the side rail at the bottom flat edge. You only need 4 of the 8 bolts now, you will use all of them for the Full bed. Do not tighten until all four bolts are at least started half way in their holes. Tighten bolts so they are SNUG, but there is no need to over-tighten as you could pull the inserts out of the wood.
5. Replace the mattress deck and mattress and you are ready for your Toddler to enjoy his/her new "big boy bed"!



**Full-Size Bed:** Transitioning from the Toddler Bed to the Full-size bed is very simple, and you will need to get that Front Gate back out of storage, as well as the long metal & half-log side rails, and the remaining bolts. Now you're removing the 2 side panels, stretching out the Footboard/Gate with the 2 long side rails. You will need to turn the Headboard/Back Panel around so you can access the metal inserts on the opposite side of the posts. You will also need your wrench or socket again for the bolts.

1. Remove the mattress and mattress deck, and put away in storage until you have another baby or pass it on to your grandchildren.
2. Remove the front short rail by loosening and removing all of the bolts, set bolts aside, as you will need them again for the Full bed.
3. Remove all 8 of the wood screws holding the side panels inside the posts. Remove the Side panels and individual front posts, and store in safe, dry place.
4. Turn the Back Panel/Headboard around so the inserts are facing you and the holes are now facing the wall. Position the Footboard/Gate facing the Back Panel so the inserts and holes are facing the Headboard. Line up the long metal & half-log side rails up on each side with the corresponding red numbers.



5. Bolt the side rails into their respective places, halfway only, do not tighten yet. Once all the bolts are started half way, go ahead and tighten them SNUG, do NOT overtighten.



6. Your new full bed is now ready to accept your full-size mattress and boxspring (not included).